



347 C



2735 C



k



**INSTRUCTIONS**

Pour an adequate quantity of reference solution into a clean container. Immerse the pH electrode in pH reference solution for 1 minute before calibrating. To extend the life of your pH meter, keep electrode immersed in a small cup of pH reference solution when the meter is turned off. Rinse the electrode with distilled water after each pH reading to avoid contamination of the storage reference solution. Replace storage solution often. Never pour used solution back into this bottle.

**Standard  
Reference  
Solution @ 25°c**  
*for calibration of  
pH meters and  
electrode storage*

**pH 7.0**

**KEEP OUT OF REACH OF CHILDREN**

**STORE IN A COOL DARK PLACE**

**MIX THOROUGHLY**

**Net Contents 1 Quart (946 ml)**



Manufactured By: General Hydroponics  
2877 Giffen Ave, Santa Rosa, CA 95407  
(800) 374-9376  
©2017 General Hydroponics.  
World rights reserved.



7 53054 01552 3  
10102-1552-2 LB91535A p051418am